



Target Turner System Operation

BEFORE YOU BEGIN

- Please read all instructions and safety guidelines before operating
- Make sure that the motor housing is fully charged before use
- The power adapter light will shine green once fully charged
- Install 4 AA Batteries into the remote controller

POWERING ON

- Switch on the motor: |
 - A red indicator light will turn on
- WARNING!** Target arm will rotate to home position once powered on

- Switch on the remote controller: ●
- A green indicator light will turn on

PAIRING

- To ensure proper operation, power on the motor housing before powering on the remote controller

POWERING DOWN

- Switch off the remote controller: ○
- WARNING!** Target will continue to rotate until the motor is switched off
- Switch off the motor: ○

Remote Control Operation

<p>Power On Motor</p> <p> On</p> <p>○ Off</p> <p>WARNING! Target arm may rotate to home position once powered on</p> <p>Power On Remote Controller</p> <p>● On</p> <p>○ Off</p>	<p>☰</p> <p>< ></p> <p>2x <> 180°</p>	<p>Manual Mode (Left, Home, Right)</p> <p>2x tap Left/Right for a 180° rotation</p>
<p>☰ Toggle/Select Mode</p> <p>Manual: Have another person control the target</p> <p>Unholstered: Firearm safely out and ready. Target remains in home position for a shorter random time interval</p> <p>Holster: Firearm safely in holster. Target remains in home position for a longer random time interval</p>	<p>☰ ⌚</p> <p>⌚</p> <p>⌚ 1.5s</p> <p>⌚ 3s</p> <p>⌚ 5s</p>	<p>Unholstered Mode</p> <p>Toggle clock to select timer</p> <p>1.5 sec Target Presentation</p> <p>3 sec Target Presentation</p> <p>5 sec Target Presentation</p>
	<p>☰ ⌚</p> <p>⌚</p> <p>⌚ 1.5s</p> <p>⌚ 3s</p> <p>⌚ 5s</p>	<p>Holster Mode</p> <p>Toggle clock to select timer</p> <p>1.5 sec Target Presentation</p> <p>3 sec Target Presentation</p> <p>5 sec Target Presentation</p>



Remote Pairing Process

- Step 1) Motor: Off**
 - Step 2) Remote: Off**
 - | **Step 3) Remote:** Hold the middle **Home** button down
 - **Step 4) Remote:** While holding the **Home** button down, Turn **On** the Remote
 - | **Step 5) Remote:** The top row of lights will start flashing ● ● ● ● ● ●
 - Step 6) Motor:** Now turn **On** the Motor. The lights on the Remote will stop flashing once the Motor is powered on
 - <> **Step 7) Remote:** Press the **Left Arrow** or the **Right Arrow** until the far right light is the only light on ○ ○ ○ ○ ○ ●
 - ≡ **Step 8) Remote:** Now press the **Toggle/Select** button. The lights will flash a few times and then land back on the far right light
 - **Step 9)** Now turn both the Remote and the Motor **Off**
 - Step 10)** Power both the Remote and Motor back **On**
- Your device is now paired!**

Note: You can have up to 6 turners independently operating in one area. In step 7, you can assign each turner a frequency channel by selecting one of the 6 individual LED positions. Each LED position represents one channel.

By selecting the same frequency for all turners, they can be operated by one single remote control.





Installing the Turner Module on the Target Carrier

1. Before installing it, charge the target turner module using the provided adapter
2. Install AA batteries inside the remote control
3. Verify operation
4. Install the turner module on the central part of the carrier plate, where 2 middle holes are located
5. Install the 90 degrees adapter on the target module and secure it in place
6. Install the target bar and attach the target holder
7. Done



Used for Target Turner module

